V.1.2

NAVIGATION QUICK START GUIDE ENGLISH

CAR MEDIA SYSTEMS

CAMPER & TRUCK EDITION

VISION NAVICEIVER

Getting started

When using the navigation software for the first time, an initial setup process starts automatically. Do as follows:

☞ Select the program language. If your preferred language does not appear on the screen, tap / or drag the list up or down with your finger to view all available languages. Tap English (UK) to select your preferred language. Tap Done to confirm your selection, and proceed to the next page.



☞ Read the Software and Database End User Licence Agreement, and tap Accept if you agree with the terms of use.

☞ You are now asked whether you allow the software to collect usage information and GPS logs that may be used for improving the application and the quality and coverage of maps. Tap Yes to allow the anonymous statistics or disable this function.

☞ Select the voice guidance language profile. If your preferred language does not appear on the screen, scroll the list for other available profiles. Tap any item in the list for a short voice sample. Tap Next to confirm your selection, and proceed to the next page.

Getting started



☞ Set your preferred time format and units. Tap Next to confirm your preferences.



☞ Set your preferred route planning options. Tap Next to confirm your preferences.

If necessary, open the "Select Vehicle" menu and select your type of vehicle.



Getting started

If necessary, open the settings for the vehicle-specific parameters, such as length, width, height and weight.





Confirm and exit these settings by tapping twice

Back

and confirm your route settings by

Done



The initial setup is now complete. Tap Finish.

The application starts.

Startup screen: the Navigation menu

After the initial setup, and whenever the software is started, the Navigation menu appears. You have the following options:

- Tap 

to select your destination by entering an address or selecting a place of interest, a location on the map or one of your Favourite destinations. You can also look up your recent destinations from the Smart History or by entering its coordinate.
- Tap

to display the route parameters. You can view the route in its full length on the map. You can also perform route-related actions such as editing or cancelling your route, setting a start point for the route, picking route alternatives, avoiding parts of the route, simulating navigation or adding the destination to your Favourites.
- Tap 

to customise the way the navigation software works, simulate demo routes, or to run some additional applications.
- Tap

to start navigating on the map.
- Tap
to stop navigation and exit the software.
- Tap
to show up-to-date traffic information, if an optional TMC module is connected to the device.

Find menu



In the Navigation menu, tap

. The Find menu provides you with thefollowing options:

- Tap

to specify an address as your destination.
- Tap

to select a place of interest as your destination.
- Tap

to navigate to a location selected on the map.
- Tap

to choose from the list of your favourite destinations.
- Tap

or

to navigate to the recent destination that is shown on the button.
- Tap

to choose from the list of all recent destinations.
- Tap

for other search methods.

Navigating to an address

In the Navigation menu, tap

, then tap

By default, the screen proposes the city or town where you are located.

☞ If needed, change the country. Tap the button showing the name of the country.

1. Use the keyboard to enter the name of the country.
2. After entering a couple of characters, the list of countries that match the entered string appears. Tap the country of your choice.

☞ If needed, change the city/town. Tap the button showing the name of the city/town, and use the keyboard to enter a part of its name. As you enter letters, the most likely city/town name is always shown in the input field. You have the following options:

- Tap to select the city/town that is offered in the input field.
- Tap to correct your entry.
- Tap

to browse the list of city/town names matching your input. Select a city/town from the list.

Navigating to an address

☞ Enter the street name:

1. Tap **<Street Name>**.
2. Use the keyboard to enter a part of the street name.
3. Tap to select the street that is offered in the input field or tap Results to browse the list of all streets matching your input. Select a street from the list.

☞ Enter the house number:

1. Tap **<House Number>**.
2. Use the keyboard to enter the house number.
3. Tap Done to finish entering the address.

☞ The map appears with the selected destination in the middle. Tap another map location if necessary, then tap Next to confirm the destination.

☞ After a short summary of the route parameters, the map appears showing the entire route. Wait for a few seconds or tap Go! and start navigating.

Navigating to a place of interest





On the Map screen, tap Menu to return to the Navigation menu. In the Navigation menu, tap Find, then tap Find Places. You are offered the following preset search categories:

- Tap Petrol Station Along Route to get a list of petrol stations along the route or if it is not available, around your current position or your last known position.
- Tap Parking At My Destination to get a list of parking lots near the destination or if it is not available, around your current position or your last known position.
- Tap Restaurant Along Route to get a list of restaurants along the route, around your current position or your last known position.
- Tap Accommodation At My Destination to get a list of accommodation near the destination, around your current position or your last known position.

You can also tap Quick Search Along route and search for a place by entering its name.

If none of the above is appropriate, tap Custom Search to find a place of interest at the following locations:

- Tap **Around Here** to search around the current position or if it is not available, around the last know position.
- Tap **In a Town** to search for a place within a selected city or town.
- Tap **Around Destination** to search for a place around the destination of the active route.
- Tap **Along Route** to search along the active route, and not around a given point. This is useful when you search for a later stopover that results in a minimal detour only, such as searching for upcoming petrol stations or restaurants.

An example of navigating to a place of interest





Example: To find a park around your destination, do as follows (starting from the Navigation menu):

☞ Tap Find.

☞ Tap Find Places.

☞ Tap Custom Search.

☞ Tap **Around Destination**.

☞ The list of place categories appears. Tap ▼ or slide your finger to browse the list, and tap Leisure.

☞ Tap List All Places to browse the whole category, or tap Park and Recreation Area to narrow down your search.

☞ Tap any of the list items.

☞ Check the details and the location of the place, and then tap Next.

☞ After a short summary of the route parameters, the map appears showing the entire route. Wait for a few seconds or tap Go! and start navigating.

The Map screen

The Map screen is the most important and frequently used screen of the software. The Vehimarker (a blue arrow by default) represents your current position, and the orange line shows the recommended route. There are screen buttons and data fields on the screen to help you navigate. During navigation, the screen shows route information.

- At the top of the screen, you see your heading and the house numbers on left and right if you have not selected a route destination. When navigating a route, you see the next manoeuvre and the next street/road on your route. Tap either of them to open the route itinerary.
- Tap to open the Quick menu with a selection of functions that are useful during navigation.
- Tap the map anywhere to explore the map around your current position. Additional map control buttons appear.
- Tap

to open three data fields on the map. Tap any of them to suppress the others. The default values for navigation (you can change them in Map settings):
  - the remaining distance to the destination,
  - the remaining time of the trip, and
  - the estimated time of the arrival at the destination.
- Tap

to open the Navigation menu.

'More' menu



The 'More' menu provides you with various options and additional applications. In the Navigation menu, tap 

.

-

: Fine-tune route planning options, change the look of the Map screen, turn on or off warnings, or restart the Configuration wizard, etc.
-

: Visit www.naviextras.com to get additional content, such as new maps or 3D landmarks and useful applications.
-

: Access travel applications: the unit converter, the clothing size converter or country information.
-

: Access other useful applications: the calculator, the fuel and maintenance monitor or the trip and track log monitor.
-

: Run the Demo and watch sample route simulations to see how navigation works, read the Software and Database End User License Agreement, or check the map and other contents of the application.

Settings menu





In the Navigation menu, tap 

, then tap

. The Settings menu provides you with the following options (scroll the list to see all):

- 

: Adjust the different sound volumes, change the voice guidance profile, or enable and set up warnings.
- 

: Change the function buttons in the Quick menu of the Map screen.
- 

: Before selecting one of the Lorry profiles as the Vehicle type used in route calculation, set up the editable lorry attribute profile with the parameters of your lorry. These parameters will be used in route calculation.
-

: You can adjust traffic related settings such as using preloaded statistical or online traffic, or select whether to take traffic events into consideration when calculating the route.
-

: Select the type of vehicle you are driving, the road types used in route planning, and the route planning method.
- 

: Adjust map related settings: change the daytime and night colour schemes, change the default zoom level, switch between 2D and 3D map, suppress buildings or change the Vehimarker.
-

: Adjust how the software helps you navigate with different kinds of route related information on the Map screen.
-

: Turn the menu animations on or off, select a different skin for the application, or adjust the display backlight.
-

: Change the program language, the time format, units or the time zone.
-

: Turn the automatic trip or track log saving on or off, check the current size of the trip database.

-

: The application collects usage information and GPS logs that may be used for improving the application and the quality and coverage of maps. Here you can enable or disable collecting these logs.
- 

: Modify the basic software parameters set during the initial setup process.
- 

: Delete all saved data and reset all settings to their factory defaults.

CAR MEDIA SYSTEMS

ESX Car Media Systems · Audio Design GmbH
Am Breilingsweg 3 · D-76709 Kronau/Germany
Tel. +49 7253 - 9465-0 · Fax +49 7253 - 946510
www.esxnavi.de - www.audiodesign.de
All Rights Reserved