

V1.1

OWNER'S  
MANUAL



CAR MEDIA SYSTEMS



**VN1040-4G**

**SMART NAVICEIVER**  
**MOBILE INTERNET READY**  
VISION ANDROID™ SERIES

**Always follow the instructions in this manual before using the device. Please keep this manual easily accessible in the vehicle for future reference.**

<b>Disclaimer</b> .....	<b>3</b>
<b>Intended use of the device</b> .....	<b>3</b>
<b>Disposal</b> .....	<b>3</b>
<b>Declaration of conformity</b> .....	<b>3</b>
<b>General Information</b> .....	<b>4</b>
<b>Safety Information</b> .....	<b>5</b>
<b>1. Brief Overview</b> .....	<b>6</b>
1.1 Function keys.....	6
1.2 Operation .....	7
1.3 Status bar.....	7
1.4 Time and date settings.....	8
1.5 Language .....	8
1.6 Display / key illumination.....	9
1.6 Reset button.....	9
<b>2. Basic settings</b> .....	<b>10</b>
2.1 Customized main menu.....	10
2.2 Background image.....	13
2.3 Split screen.....	14
2.4 Steering wheel control.....	15
2.5 Internet connection via WIFI.....	16
2.6 Internet connection via 4G/LTE .....	17
2.7 DSP / audio settings.....	18
2.8 Set-up navigation.....	19
2.9 Rear view camera.....	20
2.10 Additional camera.....	21
2.11 360 ° view (depending on equipment).....	22
<b>3. Infotainment</b> .....	<b>24</b>
3.1 Radio .....	24
3.2 DAB+ Radio.....	25
3.3 Bluetooth® / BT Music .....	26
3.4 Audio Player .....	28
3.5 Video Player .....	29
3.6 Media Connect / Phone Link (depending on equipment) .....	30
3.7 Easy Connection .....	30
3.8 AV-IN .....	31
3.9 Gallery .....	31
3.10 File Manager / ES File Explorer.....	32
<b>4. Updates</b> .....	<b>33</b>
4.1 MCU / System Updates .....	33

## DISCLAIMER

---

### Dear customer,

The Android operating system is an open platform that allows you to personalize your device according to your wishes. You can download apps from the Google Play Store after registering and using them on your device.

### SAFETY INSTRUCTIONS & DISCLAIMER:

The company Audio Design has no influence on the content or function of these apps. For this reason, we can not assume any liability for the functionality, operation or damage resulting from the download and / or use of apps. Audio Design can not provide service for the apps installed or installed on the device. Use is always at your own risk. If you have any questions, especially about content or how it works, please contact the developer of the app.

To ensure the safety of the driver, the occupants and other road users, it is essential that the driver always focuses on the traffic.

**ATTENTION:** Your ESX device has an internal memory with a limited capacity. By downloading apps, pictures and music you fill up this memory. When the memory is full, there is a possibility that apps may stop working or be of limited use. If so, you'll need to delete apps or content to restore the feature. You are responsible for the management of the store.

## INTENDED USE OF THE DEVICE

---

This device is only suitable for use in a vehicle with an on-board voltage of 12 volts, negative ground. In the event of misuse, incorrect installation or changes, the operating license and the warranty become void.

## DISPOSAL

---



If you have to dispose of the device, please note that no electronic devices may be disposed of with household waste. Dispose of the device in a suitable recycling facility in accordance with local waste regulations. If necessary, consult your local authority or your dealer.

## DECLARATION OF CONFORMITY

---

**CE** **Distribution:**  
Audio Design Lautsprecher Vertriebs GmbH  
Am Breilingsweg 3, DE-76709 Kronau/Deutschland

The Audio Design Lautsprecher Vertriebs GmbH hereby declares that the radio system type **VN1040-4G** complies with Directive **2014/53/EU**. The full text of the EU declaration of conformity is available at the following Internet address: **[www.esxnavi.de/ce](http://www.esxnavi.de/ce)**

## GENERAL INFORMATION

---

### Legal Notice

- ESX or Audio Design GmbH are in no way affiliated with the car manufacturer or any of its subsidiaries or affiliated companies connected to, or is acting on its behalf or with its authorization.
- All registered product names, trade marks and brands are the property of their respective owners.
- This owner's manual was made with the utmost care.
- Technical changes and errors reserved.

Due to the ongoing development of this device, it is possible that the information in this manual is incomplete or is not matching to the delivery status.

Please visit periodically [www.esxnavi.de](http://www.esxnavi.de) on the internet, to check if additional information and updates are available.

### Customer service

In general, the assembly and installation of the device should be made by a trained and technically skilled specialists.

If you have any problems with operating the device, contact your specialist dealer or the Audio Design Service Department under Tel. **+49 7253 - 94 65 95** or by E-Mail to [navi@esxaudio.de](mailto:navi@esxaudio.de).

### Care and Maintenance

This device is equipped with high precision and sensitive technique and should always be treated with caution. Please note the following tips to avoid endangering the warranty and extend the life of the appliance.

- Children under 12 should not operate the device. Keep the device and all accessories away from small children.
- Keep the device and its components dry. The effects of water, liquid or moisture can cause damage to the vehicle, the device itself or injury.
- Keep the device and its components away from excessive heat. High temperatures may shorten the life of appliance of the electrical components.
- Keep the device and its components away from excessive cold. Extreme temperature changes and moisture inside the device may cause the breaking of certain components. Do not to drop the device and avoid violent shocks or excessive shaking.
- Do not use strong chemical cleaners, solvents or water to clean the device. Use a slightly moistened cotton cloth.
- Replace a blown fuse only with a new one with the same values. However, before replacing a defective fuse, first check what the cause of the short circuit is. Start with the power cable. If the fuse blows again, there is a malfunction in the device. In this case, you should contact your authorized dealer.

## SAFETY INFORMATION


---

- Note any time the traffic regulations of the country in which the device is operated.
- Please ensure, that with the engine turned off the vehicle's battery does not discharge fully. The device is another electrical consumer which must be operated with the engine running, other-wise the vehicle's battery will be discharged and the vehicle can not be started.
- Set the volume of the device only as loud, that you are still be able to hear warning signals (e.g. police sirens) and traffic noise inside the vehicle.
- Operate the device as driver only if it's absolutely necessary and in the driving safety is not compromised. The same stands for looking at the screen. If necessary, better park your vehicle at a safe and appropriate location.
- The traffic rules of the EU prohibit to view moving pictures or movies while driving, if the screen of the device is installed within sight of the driver, as he may be distracted. View the screen as driver only for the navigation function, and then only briefly that you will not be distracted. Note at any time the local traffic regulations. In an accident, regress claims could be made by the car insurance company.
- This device is not a substitute for your personal judgment or perception. All suggested routes from the navigation system should never be taken as a reason to disregard the local traffic rules. Your personal assessment of traffic or your knowledge of safe driving practices is paramount. Always match your driving with the current traffic situation.
- Do not follow the suggested routes, if the navigation system instructs you to take an unsafe or illegal way, puts you in an unsafe situation, or directs you into an area which you consider unsafe.
- If problems occur while driving, park the vehicle in a safe and appropriate place to continue before you operate.
- Please use only the included original accessories. Ensure a sufficient mounting of the device by using the included installation accessories, as in the event of an accident enormous accelerations may occur. Poorly installed devices and equipment in accidents could represent a severe risk to the driver and the other passengers of the vehicle.
- Note under all circumstances the regulations and advice of the vehicle manufacturer and do not make any modifications to the vehicle, which could interfere with safe driving. Please treat all parts of the device and the components of your vehicle always with caution.
- Please avoid short circuits and make sure that no metal objects can get inside the device. Also make sure that all connections are properly connected and avoid the interchanging of the polarity of all connections. Complete the installation only while the ignition is turned off.
- In the event of a defect or malfunction, do not attempt to repair it by yourself or open the device, this is dangerous and could cause injury or damage to the equipment or vehicle. A repair should be done by trained and authorized personnel only. The device uses a Class 1 laser to read the disk. Eye contact with a laser is very dangerous to the human eye.
- If you connect an external device, you should first read the instruction manual of the external device and make sure that it is compatible. Avoid connecting an incompatible external device.
- If you install external applications onto the operating system of the device or operate files, make sure that they are „virus free“ and compatible with Android™. Otherwise there is a risk that the operating system no longer works properly and must be reinstalled.
- Do not damage or scratch the screen with sharp objects. Do not operate the screen with hard objects.

# 1. BRIEF OVERVIEW

## 1.1 FUNCTION KEYS

Internal microphone



Symbol	Function	Description
	Switching on or off with or without ignition	Press and hold the button for more than 3 seconds to turn the device on or off without ignition.
	Mute	Press the button briefly during operation to switch the mute function on or off.
	Camera direct button	Press here to open the view of the connected rear view camera. Press again to exit.  How it works with a connected additional camera: Press here twice to open the view of the connected additional camera (see page 21). By pressing the HOME button on the device, you return to the main menu in the additional camera view.
	Main Menu	Press here to open the main menu.
	Increase the volume	Tap here to increase the volume.
	Decrease the volume	Tap here to decrease the volume.

# 1. BRIEF OVERVIEW

## 1.2 OPERATION

This device has five freely assignable main menus that you can access with a swipe to the right or left to the edge of the screen. You can recognize the main menus by their colored background. You can start any app or widget by briefly tapping the respective icon. If you hold down an icon, it can be moved.



-  Touch the screen (briefly)
-  Touch the screen (long)
-  Press down and move

## 1.3 STATUS BAR

Symbol	Function	Description
	Back	Press here to go to the previous open menu.
	Main menu	Press here to open the main menu.
	Split screen	Screen split by 2 apps.
	Time	Current time display.
	Switch off the monitor	Press to turn off the monitor but not the device. To turn the monitor back on, tap on the screen.
	WiFi	WiFi signal detected, the device is connected to the wireless network.
	4G / LTE	4G / LTE signal detected, the device is connected to the mobile internet.
	Bluetooth®	Bluetooth® signal detected, the device is connected to another device via Bluetooth®.
	USB	A USB storage medium is connected.

The symbols  on the left side of the status bar are used for menu navigation or show the apps or notifications and events used. If there is a new message, it will be displayed in the status bar. Then you could click on the message and see its contents. The icons on the right side of the status bar are the device status indicators.

**Important note: Depending on the apps or optional accessories used, the status bar may vary as shown here!**

# 1. BRIEF OVERVIEW



---

## 1.4 TIME AND DATE SETTINGS

---

This device has the function of automatically calibrating the current time via active GPS reception. You can also set the date, time zone, and format manually. If you tap on the widget with date and time in the main menu, you will also be taken directly to this menu.



- Apps
  - > Settings
  - > System
  - > Date & time
  - > Set date
  - > Set time
  - > Select time zone



## 1.5 LANGUAGE

---

- Apps
  - > Settings
  - > System
  - > Language & input
  - > Check the input method according to user's requirements, for example "English"



**Note:** Now move your choice to the first position with a swipe, that the operating system displays your preferred language. If your selected language is not available in certain menus and functions, the next language will be used.

# 1. BRIEF OVERVIEW


---

## 1.6 DISPLAY / KEY ILLUMINATION

---

In the display menu you can make settings for the display brightness, the key illumination and the screen saver function.

- Apps > Settings
- > Car settings
- > Display



## 1.7 RESET BUTTON

---

If the device no longer reacts to inputs, the system is overloaded or has crashed. Then reset the device by pressing the reset button (RST) on the front panel. After pressing the reset button, the system restarts without losing the settings you have already made.



Use a suitable object, such as a paper clip or a ballpoint pen.

## 2. BASIC SETTINGS

### 2.1 CUSTOMIZED MAIN MENU

#### BASIC APPS IN THE MAIN MENUS


In each of the five main menus there are six basic apps at the bottom, which you can freely define. To move or delete an app, press and hold it and drag the app to another location or move the app to the trash.



Basic apps in the main menu.



To be able to place a new basic app, you must first create space for it. For example, pull the radio app to the bottom right.



Then drag e.g. the DAB-Z app to the front.



Then place it in the free space.



The app is now in the basic app bar.



It will now appear on every main menu.


## 2. BASIC SETTINGS

### APPS IN THE MAIN MENUS

You can freely move any app or widget to the main panel of any main menu. In total, you can assign all five main menus to suit your needs.




Tap on Apps in the lower right.



For example, pull Maps forward. You can access more apps by swiping left.



Place the app on the main control panel in one of the main menus.



The apps are displayed in alphabetical order in the app menu. You start an app by tapping on the respective symbol.

### WIDGETS IN THE MAIN MENU

Widgets are graphic windows that display, for example, the date and time. In the standard main menu there is initially a widget which you can move to the left if necessary.



Standard main menu.




Slide the widget to the left.


## 2. BASIC SETTINGS




To place another widget in the free space, tap Apps in the lower right corner.



Tap on WIDGETS in the app menu,



To select the Media widget, swipe left to view the next page of the menu.



Drag the widget you want upwards.



Place the Media widget in the free space on the right.



The media currently being played are now shown on the right-hand side of the main menu, including the control buttons, e.g. the audio player or the radio app.

## 2. BASIC SETTINGS



In order to place a new widget, the position must first be cleared again. To do this, drag the widget to the bottom right.




The right side of the main menu is now freely assignable again.

### 2.2 BACKGROUND IMAGE

You have the option of changing the background of the five main menus as you wish.



Tap a free field on the main screen for about two seconds.



For example, type on wallpapers.



Select the background image you want by tapping Set wallpaper.

If you want to use your own background, it should be in the format 1024 x 600 pixels and have a sufficiently high resolution. After you have copied the file to the device, you can select it via the ES File Explorer or the gallery (see above).


## 2. BASIC SETTINGS

### 2.3 SPLIT SCREEN


Tap in the status bar on 



All currently used or recently used apps can be seen in this selection.




Select the app you want and slide the window all the way to the left until it clicks into place.



The primary app is now always displayed on the left. Now select an app for the right side (e.g. audio player or DAB+ radio).



The secondary app on the right can be changed by starting another app in the main menu.



If you want to dissolve the split screen again, drag the black frame in the center of the picture to the left or right.

**Important note: Some apps are not suitable for display in split screen mode.**

## 2. BASIC SETTINGS

---

### 2.4 STEERING WHEEL CONTROL

---

Here you can define the control buttons of your steering wheel and synchronize them with the device.

- Apps > Settings
- > Car settings
- > SWC



**Important note: Some vehicles are not compatible. The device is CAN bus compatible, but you may need a vehicle-specific adapter or module.**

- A. First tap on CLEARALL and then on a desired function.
- B. Then press the appropriate button on the steering wheel. If the entry is shown successfully on the display, the corresponding color on the button changes.
- C. Repeat steps A and B until you have made all the settings.
- D. Exit the menu when the settings are complete.


**Important note: If you want to reset the steering wheel assignments and learn the functions again, press "CLEARALL" and repeat the process.**

## 2. BASIC SETTINGS

### 2.5 INTERNET CONNECTION VIA WIFI / HOTSPOT

In order to be able to fully use the Android™ operating system, such as Google Maps, it is useful to connect the device to the Internet via Wi-Fi. All you need is a smartphone with a mobile internet connection and the so-called hotspot function.

- > First, enable the Wi-Fi / Hotspot feature on your smartphone
- > Then open “Settings” in the main menu.
- > Click on Network & Internet
- > Click on Wi-Fi and be sure, this function is activated.



Click on your smartphone network in the list.




To display the keyboard for entering the password, tap the field above the green line.



Then enter the password of your smartphone network and press the green tick to connect.

After a successful entry, the device should be connected to your smartphone after a few seconds.



If you click on the network name again in the „Connected“ status, you will receive some information about the currently active Internet connection. If you want to interrupt the connection to your smartphone, click on „Remove“. However, you must then enter the password again when you reconnect.

**Note: Depending on the operating system and type of smartphone, you may need to restart the Wi-Fi / Hotspot feature if the connection with the device has been lost. It is therefore advisable to have the Wi-Fi / Hotspot function permanently activated on your smartphone.**

## 2. BASIC SETTINGS


### 2.6 INTERNET CONNECTION VIA 4G/LTE

To connect the device to the Internet via an optionally connected 4G/LTE dongle, please proceed as follows:


- > Turn off the device and have your PIN code ready to unlock your SIM card
- > Then connect the 4G/LTE dongle with antennas to the device
- > Put your SIM card in the SIM card slot of the dongle (Refer to the Installation Guide of the ESX device)
- > Turn the device on again




After the device has started, enter your 4-digit PIN code of the SIM card here. Confirm the entry with the tick.



After successful entry, the SIM card is unlocked.



If the device is successfully connected to the mobile Internet, the “4G” symbol appears in the status bar at the top right.



If the device is switched off, you have to enter the PIN code of the SIM card again after each restart, just like with a smartphone.

**Note:** You can also deactivate the request for the PIN code of your SIM card so that you do not have to enter it again after each device start. To do this, insert the SIM card into a smartphone and deactivate the request for the PIN code in accordance with the instructions of the mobile network operator or the smartphone manufacturer.

## 2. BASIC SETTINGS

### 2.7 DSP / AUDIO SETTINGS


Tap DSP in the app menu. Depending on the app, the audio settings are also located in the respective app menus, such as in the radio or music app.



Here you can select different equalizer presets or change the EQ controls directly as you wish.



In this menu you can activate a high and / or low pass filter for the audio signal. Set the respective switch to the ON position and select the desired crossover frequency.



In this menu you can adjust the balance between the right and left speakers and the fading between the front and rear speakers. To do this, press the arrow buttons to set the desired position.

If you are using an external audio amplifier, slide the EXT AMP switch to the ON position.



On the right side there are further menus for advanced audio settings.

## 2. BASIC SETTINGS



---

### 2.8 SET UP NAVIGATION

---

Here you can specify which navigation application is started when you press the MAP function key on the device or tap on the Navi app icon in the main menu.


- Apps > Settings
- > Car settings
- > Navigation
- > For example: Google Maps or iGO



## 2. BASIC SETTINGS


### 2.9 REAR VIEW CAMERA

If you have connected a compatible rear view camera to the camera input of the device, the camera image is automatically displayed when you engage reverse gear. This view is also shown when the camera direct button is pressed.



If your rear-view camera does not have dynamic warning lines, you can use the device's static parking lines.

In Settings, open the Auto Settings menu, then tap Video. Activate the warning lines or mirror the camera image there.



When you tap the display, a gear symbol appears in the top left. Tap it to open the camera view settings.


Here you can make various settings according to your requirements. Exit the settings with the red X.

**Important note: If no camera is connected, this view shows "No Signal".**


## 2. BASIC SETTINGS

### 2.10 ADDITIONAL CAMERA

If you have connected a compatible additional camera to the additional camera input of the device, this will be displayed via the F-CAM app. This view is also shown when pressing the camera direct button twice (refer to page 6), if the additional camera has been activated before.



Under Settings, open the Car Settings menu, then tap on Video. Activate the corresponding input under Front Cam.



If a time selection is made here instead of ON, e.g. 5s, the application closes automatically after 5 seconds and the main screen is shown again.



Tap on F-CAM in the app menu to open the additional camera view.



To exit the view, tap the white X in the top right corner.



Alternatively, you can also connect a double-lens reversing camera with far vision, which you can then use as a rear-view mirror camera via the F-CAM app.




As soon as you engage reverse gear, the close-up view of the rear-view camera is activated again.


## 2. BASIC SETTINGS

### 2.1.1 360° VIEW (DEPENDING ON EQUIPMENT)

If you have connected four compatible HD cameras to the camera inputs of the device, you can operate the all-round cameras accordingly using the 360° View app in the app menu.



Tap the screen to reveal the control buttons for that menu.




The four connected cameras can be selected with the control buttons above. The selected camera is then shown on the right. On the left you always see the all-round view of all four cameras.




The lower control button 3D activates the interactive all-round view. This starts to rotate automatically.




However, you can also move the depicted vehicle in the middle to swipe to the desired view.




The lower control buttons offer further functions, such as a PIP camera display, the parking mode and other settings.



Here you can make further settings for the connected cameras.



The record button is located at the bottom left. With this, all four connected cameras are recorded in one image and saved as a TS-MPEG-2 file (transport stream) on the device in the Films folder. This video file can only be played with a special video player and not on the device itself. IMPORTANT: Please observe the data protection regulations of your country for recordings in public traffic.



When the reverse gear is engaged, the above view is automatically displayed. This view is also shown when the camera direct button is pressed. On the left you always see the all-round view of all four cameras and on the right the reversing camera at the rear of the vehicle.

**Important note: If no camera is connected, this view shows „No Signal“.**

## 3. INFOTAINMENT

---

### 3.1 RADIO

---

Press the Radio button on the device or tap Radio in the main menu to open the Radio menu.

Symbol	Function	Description
	Volume	Tap here to adjust the volume.
	Mono-/Stereo Operation	Tap here to switch between mono and stereo operation. With weak stations, the reception quality usually improves in mono mode.
	FM	Tap here to switch to the FM frequency band.
	AM	Tap here to switch to the AM frequency band.
	Station search	Tap here to automatically search for and save all radio stations in the reception area.
	Audio settings	Tap here to open the audio settings.
	Radio OFF	Tap here to turn off the radio. The device then switches back to the main menu.
	Next station down	Tap here to search for the next strong and clear station frequency band downwards.
	Next station up	Tap here to search for the next strong and clear station frequency band upwards.
	RDS	Tap here to show the RDS options.
	AF	Click AF to activate the AF function. This function enables automatic switching when leaving the reception area of an RDS radio station. The device automatically switches to another frequency if the same program is also available in a different reception area.
	PTY	The PTY function is a classification of radio stations in different categories. Every program on an RDS radio station is categorized. After you have selected a category, the device automatically searches for the next suitable radio station in this category.
	TA	Click TA to activate the TA function. This function enables the interruption of media playback (audio player, media connect, etc.) for traffic announcements. After the announcement, the previous media playback starts again.

### 3. INFOTAINMENT




To save a station in the favorites, press for one second on the desired position.

The station is now in the favorites list.

### 3.2 DAB+ RADIO

In the app menu tap on DAB-Z. When using the device for the first time, you must first start the station search as requested. This process can take several minutes. All DAB+ stations displayed in the current transmission area will then be displayed.

Symbol	Function	Description
	Next station down	Tap here to search for the next strong and clear station frequency band downwards.
	Next station down up	Tap here to search for the next strong and clear station frequency band upwards.
	Favorite list / channel list	Tap here to switch between the favorites list and the channel list.
	Settings	Tap here to open the settings.



To save a station in the favorites, press the station name in the list for a second and select the star. To delete the station from the favorites list, select the trash can.

In the settings, for example, you can start a station search for all stations that can be received in the reception area under station list.

## 3. INFOTAINMENT

### 3.3 BLUETOOTH® / BT MUSIC


To enable wireless phone calls, audio streaming or data exchange, you must connect the device to another Bluetooth® mobile device. First you have to activate the Bluetooth function on your mobile phone.



Tap Bluetooth in the main menu of the ESX device.



At the top right, tap the magnifying glass to select your smartphone.



Tap on the name of your smartphone. You will then receive a message on your smartphone that ESX Navi wants to connect. Confirm the pairing process.



Your smartphone is now connected to the ESX device via Bluetooth and connects again each time it is started. If you want to disconnect, tap the X in the top right corner.


#### Important instructions:

1. Legal restrictions may apply to the operation of Bluetooth® devices exist. Please observe the local laws.
2. To keep the Bluetooth® connection secure, you should use a secure one and a non-public place while you connect a Bluetooth® device.
3. Do not start the initial connection while driving.


### 3. INFOTAINMENT




In the Keypad menu you can enter a number directly and start the call with the green button. End the call with the red button.



The Contacts menu is initially empty. In the top right, tap the download icon to import your smartphone's contacts.




After you have imported your contacts, you can search for contacts, delete them or mark them as favorites.



In the Call lists menu at the top you can choose between outgoing, received and missed calls. This list only shows the calls that were made via the ESX device.



In the BT Music menu you can use the control buttons below to stream music from your smartphone to the ESX device.



You can also start BT Music directly from the app menu.

**Important note: Some mobile phones require their music player to be started in order to use this function.**

### 3. INFOTAINMENT


#### 3.4 AUDIO PLAYER

Tap on the Music app in the main menu to start the audio player.


The following formats are compatible: MP3 / AAC / FLAC / WAV / AMR / M4A / OGG

The audio player accesses all files that can be found either on the internal device memory or optionally connected storage media (USB).

Symbol	Function	Description
	Volume	Tap here to adjust the volume.
	Audio settings	Tap here to open the audio settings.
	Control buttons	Tap here to start or pause playback or to play the next or previous track.
	Favorite	Tap here to mark the current track as a favorite.
	Playlist menu	Tap here to open the playlist menu.
	Random play	Tap here to turn random play on or off.
	Track repeat	Tap here to start the track repeat.



If you switch to the main menu during playback, the playback continues until you end it here or start another media app.



Here you can see the playlist menu with the available audio files, favorites and the history of the tracks that have already been played.


### 3. INFOTAINMENT

#### 3.5 VIDEO PLAYER


Tap on Video in the main menu to start the video player.

The following formats are compatible: MP4 / AVI / WMV / 3GP / FLV / SAF / MOV / MKV / MPG

Symbol	Function	Description
	Screen adjustment	Tap here to change the format of the current video or to fit it to the screen.
	Track repeat	Tap here to start the track repeat.
	Control buttons	Tap here to start or pause playback or to play the next or previous track.
	Favorite	Tap here to mark the current track as a favorite.
	Playlist menu	Tap here to open the playlist menu.
	Mono / stereo	Tap here to switch between mono and stereo playback.
	Original size	Tap here to play the video in its original size.
	End video	Tap here to stop playing the video.



If you switch to the main menu during playback, the playback continues until you end it here or start another media app.



Here you can see the playlist menu with the available video files, the favorites and the history of the titles that have already been played.

**Important note: While driving, the image signal of the video is not displayed for safety reasons.**


### 3. INFOTAINMENT

---

#### 3.6 MEDIA CONNECT / PHONELINK (DEPENDING ON EQUIPMENT)

---

If you have an iOS smartphone, you can connect it to the ESX device using its charging cable via one of the USB ports. In the settings of the iOS smartphone, you must grant the required approvals under the Car Play section.



Tap on PhoneLink in the app menu and the iOS smartphone connects to the ESX device. The Bluetooth connection is deactivated and the smartphone is charged.




In the PhoneLink menu you can now access your iOS smartphone via the touchscreen of the ESX device. As long as the smartphone is connected, the Bluetooth connection remains deactivated.

#### 3.7 EASY CONNECTION

---

If you have an Android smartphone, you can connect it to the ESX device using its charging cable via one of the USB ports. In the settings of the Android smartphone, you must grant the required approvals under the Android Auto section.



Tap on EasyConnection in the app menu and the Android smartphone connects to the ESX device.



In the EasyConnection menu you can now access your Android smartphone via the touchscreen of the ESX device.

### 3. INFOTAINMENT

---

#### 3.8 AV-IN

---

If you have connected an external audio or video source to the AUX input of the device, click on AV-IN in the app menu. Then you have to start playback on the external audio or video source.



**Important note: While driving, the image signal of a video is not displayed for safety reasons.**

#### 3.9 GALLERY

---

Start the app gallery in the app menu to view your pictures stored locally on the device or on the USB medium.



Tap on one of the pictures to open it.



For example, you can use the controls below to start a slide show or make image adjustments.


### 3. INFOTAINMENT

---


#### 3.10 ES FILE EXPLORER

---

In the app menu, tap ES File Explorer.



Here you can see which files were saved in which location. Just tap the location you want.



In the file manager, files can then be copied, moved or deleted as required to another storage medium. Just tap and hold on the desired file to mark it for further action.


## 4. UPDATES

---

### 4.1 MCU / SYSTEM UPDATES

---


After you have decompressed the downloaded update, copy the files to a USB stick. Insert the USB stick into the device.



In the following dialog, tap upgrade.



The update process starts.



After the process is complete, tap restart to restart the device.

**Important note: Please do not switch off the device during the update process.**

Visit [www.esxnavi.de](http://www.esxnavi.de) regularly or ask your specialist dealer whether update files are available for your device. Then follow the installation instructions that come with the update.



CAR MEDIA SYSTEMS



ESX Car Media Systems · Audio Design GmbH  
Am Breilingsweg 3 · D-76709 Kronau/Germany  
Tel. +49 7253 - 9465-0 · Fax +49 7253 - 946510  
[www.esxnavi.de](http://www.esxnavi.de) - [www.audiodesign.de](http://www.audiodesign.de)

© All rights reserved. Technical changes, errors and mistakes reserved.